

Safety of the rider and others is the primary concern of GDI, therefore for an added safety we are providing you with this "Warning" sticker.

Please peel sticker off and place it on the "LeanSteer" right below the key, to remind to the rider to retract the QuickStand Prior to operating the Segway PT.

To view operational video visit:
www.QuickStand.info



GreenDirections Inc.
Simply Innovative Concepts
Limited Warranty

Green Directions, Inc. (GDI) warrants to the original owner-user that this Product will be free from defects in material or workmanship.

This warranty is limited to ninety days (90) from the date of delivery, whether or not actual use begins on that date.

Limitations and Exclusions

"GDI" obligations under this warranty and the sole remedy for its breach are limited to repair, at its facility, of any part or parts of its Product which prove to be defective; or, in its sole discretion, replacement of such product. All returns of defective parts or products must include the product model number and serial number, and must be made through "GDI" Customer Service. Authorized returns must be shipped prepaid. Repaired replacement parts will be shipped by "GDI" F.O.B. shipping point.

1. The warranty provided herein does not cover charges for labor or other costs incurred in the troubleshooting, repair, removal, installation, service or handling of parts or complete product.

2. All claims under this warranty provided herein must be made within ninety days (90) from the date of delivery. Failure to notify "GDI" of a warranted defect within ninety days (90) of its delivery voids "GDI's" obligations hereunder.

3. The warranty provided herein shall be void and of no effect in the event that (a) the product has been operated outside its designed output capacity; (b) the product has been subjected to misuse, neglect, accident, improper or inadequate maintenance, corrosive environments; (c) unauthorized modifications are made to the product; (d) the product is not installed or operated in compliance with the manufacturer's printed instructions; (e) the serial number of the product has been altered, defaced or removed.

4. The warranty provided herein is for repair or replacement only. "GDI" shall not be liable for any loss, cost, damage, or expense of any kind arising out of a breach of the warranty. Further, "GDI" shall not be liable for any incidental, consequential, exemplary, special, or punitive damages, nor for any loss of revenue, profit or use, arising out of a breach of this warranty or in connection with the sale, maintenance, use, operation or repair of any Product. The disclaimers of liability included in this paragraph shall remain in effect and shall continue to be enforceable in the event that any remedy herein shall fail of its essential purpose.

5. The graphic wrap is not warranted against any damage – However if the damage was caused by the failure of the shield, "GDI" may choose but is not obligated to replace graphics free or at a discounted rate at its sole discretion.

6. THIS WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY FOR THIS PRODUCT, AND IS IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. LUCENT TACTICAL, SPECIFICALLY DISCLAIMS ALL OTHER EXPRESS AND IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No person or entity is authorized to bind "GDI" to any other warranty, obligation or liability for any Product. Installation, operation or use of the Product for this warranty is issued shall constitute acceptance of the terms hereof.

QuickStand™

Patent Pending
SEGWAY KICKSTAND

User's Manual
& Limited Warranty

GreenDirections Inc.
Simply Innovative Concepts

Group of Companies:



2944 Randolph Ave, Suite 5
Costa Mesa, California 92626
Tel: 949-334-3533
Fax: 949-334-3532
www.Green-Directions.com
info@green-directions.com

! WARNING !

This product is an aftermarket product and therefore its installation may change the performance, stability and the center of gravity of the the Personal Transporter.

Use This Kickstand at your Own Risk



DO NOT ENGAGE KICKSTAND WHILE THE SEGWAY IS IN MOTION. COME TO A COMPLETE STOP, STEP OFF THE SEGWAY, TURN OFF THE SEGWAY AND ONLY THEN PRESS DOWN WITH YOUR RIGHT FOOT ON THE KICKSTAND TO EXTEND.



DO NOT DISENGAGE KICKSTAND WHILE STANDING ON THE SEGWAY. DISENGAGE KICKSTAND PRIOR TO STANDING ON THE SEGWAY.



DO NOT ENGAGE / ACTIVATE OR APPLY KICKSTAND ON A DOWNHILL.



DISENGAGE / RETRACT KICKSTAND PRIOR TO OPERATING THE SEGWAY.



ALWAYS WEAR SAFETY EQUIPMENT SUCH AS HELMET.



DO NOT BUMP-INTO OR HIT ANY PERSON OR OBJECT.



RIDE ON SMOOTH, PAVED SURFACES AWAY FROM VEHICLES AND PEDESTRIANS.



WATCH FOR PEDESTRIANS.



DO NOT ATTACH ANY OTHER PARTS, ACCESSORIES AND/OR PRODUCTS TO THE QUICKSTAND.



OBEY ALL LOCAL TRAFFIC AND ELECTRIC VEHICLE LAWS AND REGULATIONS.

By purchasing and installing of this equipment the User agrees to defend, indemnify and save Green Directions, Inc. harmless from any and all liability, loss or damage, including reasonable attorney's fees arising out of or resulting from User's acts or omissions, negligence, violation of any laws or governmental regulation, or the acts or omissions, negligence, violation of any laws or governmental regulation of any representatives, officers, employees, or agents of User.

To view operational video visit: www.QuickStand.info

To view operational video visit: www.QuickStand.info

Thank you and congratulation on your purchase of the worlds best Segway Kickstand. The images in this installation manual will show you the proper positions the QuickStand should be installed and secured to ensure maximum stability and safety.

QuickStand Installation & Configurations

To install QuickStand simply remove the existing accessory screws on the right inner side of the Segway. Please make sure to use the right side (while standing on the Segway the screws by your "Right" foot).

Remove the screws

Place the Mounting Bracket against the Segway and Re-Insert and Tighten the Screws

This completes the installation of the QuickStand

HOW TO USE THE QUICKSTAND



THESE STEPS MUST BE FOLLOWED:

Come to a "Complete Stop", "Step Off", and "Turn Off" the Segway and then and only then using your Right Foot - Push Down all the way on the top of the Support Tube. Remove your foot once you hear and feel the Support Tube lock into place and let go of the Segway.



To Retract the QuickStand:

While the Segway is "Off" and you are OFF The Platform, pull back on the handlebar to lift the QuickStand off the ground, using your Right Foot - Press Forward against the top of the Support Tube to disengage and unlock the QuickStand.

At this point the Support Tube should spring up and retract. However, before getting on the Segway visually inspect and make sure the Support Tube is "Fully" retracted.

If and when you are certain that the Support Tube is fully retracted, Turn On the Segway and begin your ride.